


How to reset the chips

1. The cartridges are used auto reset chips(ARC), it can auto reset the chips more than million times.
2. You can mix these cartridge to use with the original ink cartridges or the other compatible ink cartridges
3. The chips are designed for their own colors, you can not swap them to use with each other in any color cartridges.

For EPN printer



Fill full inks for 1 time. can reset the chips for 2-3 times

The ink will be showed less and less when printing, as the same as original cartridges. The chips of refillable cartridge can auto reset when the printer show '0' capacity ink. If after using for a long time, the computer tells you to replace cartridge and the printer doesn't work, **Power off the printer for 1 minute, then restart ok.**
For some new model printers. keep the power on. remove and reinstall the cartridges for 1 time

How to fill inks

Open all plugs,




When filling inks
Open all plugs,
fill inks at both holes

Open the plug
that far from the nozzle



When printing
Open the plugs
that far from the nozzle

When works,



Open the holes

Install the cartridges

Atch the cartridges to the chip boxes, then install into the printer as the original ink cartridges

Clean print head without cartridges



Work without the cartridges

Remove the cartridges, only install the chip boxes in the carriage.
Clean the print head for 1- 2 times

When as below, you should clean the print head without cartridges.

1. No use the printer for a long time (2 weeks)
2. Change to different brands inks, include the original inks